Captured at: 24/09/2025 18:57 URL: https://www.musikambosse.net/assembly-pedal-usb-v1-0-de/

ASSEMBLY INSTRUCTIONS PEDAL-USB V1.0-DE

Assembly instructions / Documentation / Pedal-USB

Technical Documentation V1.0 DE / Status: 23.09.2025

- for PCB version mainboard V3.RR-rc5 from May 01, 2025
- for PCB version mainboard V3.RR-rc6 from July 31, 2025
- for PCB version mainboard V3.RR-rc6 from September 15, 2025
- for PCB version mainboard V3.RR-rc6 from September 23, 2025 (final)
- for PCB footprint PEDAL-Breakout-rc6 from August 22, 2025
- for PCB STL-Panel-rc6-Panel-v1.7 from May 25th, 2025
- Technical data PEDAL-Breakout-footprint-rc6-3D.PDF)
- BOM-Kit-Liste-KAUFHAUS_Pedal-USB (PDF)

Table of contents

1. Disclaimer
2. Soldering recommendations and tips
3. Work preparation – assembly and soldering
4. GND – Soldering of GND pads and areas
5. Preparation and sorting of components
6. Equipping the Pedal-USB Breakout Board
7. Assembly of the components: resistor, electrolytic capacitor, ceramic capacitor
8. Assembly of components Connector plug for PEDAL-USB system
9. Component placement on the Eurorack 16-pin X19 / USB-C / 16-pin connector strip X21
10. Assembly of the TB/TRS sockets / USB-A and / USB-HOST / DIP switch
11. Equipping the long connector strips
12. Check the pedal USB breakout board assembly
13. Commissioning / Functional test
14. Appendix: Additional hardware and sockets
15. The finished device NAVPANEL V2 for Microboard with the Pedal-USB option
16. Appendix A: Sources / Links / Product Recommendations
17. Appendix B: Glossary
18. Appendix C: Licenses and Copyrights
19. Appendix D: Technical Specifications Pedal USB Breakout
20. Appendix E: BOM parts list for NAVPANEL Pedal-USB
21. Appendix F: Changes since 01.07.2025

1) Disclaimer

Before you begin with the kit and assembly, we have some legal information for you. Please read the disclaimer carefully. Thank you for your understanding. The right of withdrawal and return expires as soon as the packaging has been opened. Due to the nature of the product, we cannot accept returns after opening the packaging. Use the kit for its intended purpose only. Any other use is at your own risk. Please observe the safety instructions. Assembly requires soldering skills. Soldering work may only be carried out by persons who are 18 years or older or by persons who are supervised by such persons. Soldering work may only be carried out in a well-ventilated room. Suitable protective equipment such as safety glasses and gloves must be worn. Make sure that no one is at risk from soldering work. Keep children and animals away from the soldering area. Soldering irons can cause burns. Do not touch the hot soldering iron or the soldering tip. Always place the soldering iron in a safe, heat-resistant holder when not in use. Make sure that the soldering iron is switched off and has cooled down completely before storing it away. Soldering fumes can be harmful to health. Therefore, please ensure that the workshop is well ventilated. Avoid inhaling the soldering fumes. Use a fume extractor or work in the open air if possible. Electrical safety: Make sure that the power supply is switched off before you start soldering. Check the electrical components for damage before assembly. Use only components that are in perfect condition. Fire hazard: Soldering irons can get very hot and pose a fire hazard. Make sure that there are no flammable materials in the vicinity of the soldering iron. Have a fire extinguisher or fire blanket ready in case of emergency. Environmental protection: Dispose of waste materials such as solder residue and defective components in accordance with local regulations. Do not throw them in the household waste. Liability: We accept no liability for damage caused by improper use of the kit or failure to observe the safety instructions. You are responsible for your own safety and that of others. Please read the instructions carefully before you start assembly and make sure you understand all the steps. If you are unsure about any step, please contact us or seek professional help. Have fun building your kit, but always remember safety first!

Nicole Ellrich, Diplomingenieurin und Thomas Ellrich, Musikambosse.net have given many teams that may result from injuries caused by the assembly, soldering and improper use of the NAVPANEL V3 Microboard, as well as from handling the components and the printed circuit boards.

This project involves **soldering work** and **working with electrical components**. Please read the following safety instructions carefully before you begin:

Soldering work: Soldering irons can cause burns. Do not touch the hot soldering iron or the soldering tip. Always place the soldering iron in a safe, heat-resistant holder when not in use. Make sure that the soldering iron is switched off and has cooled down completely before storing it away. Soldering fumes can be harmful to health. Therefore, please ensure that the workshop is well ventilated. Avoid inhaling the soldering fumes. Use a fume extractor or work in the open air if possible.

Electrical safety: Make sure that the power supply is switched off before you start soldering. Check the electrical components for damage before assembly. Use only components that are in perfect condition.

Fire hazard: Soldering irons can get very hot and pose a fire hazard. Make sure that there are no flammable materials in the vicinity of the soldering iron. Have a fire extinguisher or fire blanket ready in case of emergency.

Environmental protection: Dispose of waste materials such as solder residue and defective components in accordance with local regulations. Do not throw them in the household waste.

Liability: We accept no liability for damage caused by improper use of the kit or failure to observe the safety instructions. You are responsible for your own safety and that of others.

Please read the instructions carefully before you start assembly and make sure you understand all the steps. If you are unsure about any step, please contact us or seek professional help.

Have fun building your kit, but always remember safety first!

2) Soldering recommendations and tips

Use only **lead-free solder** with a diameter of 0.7 mm - 1 mm, e.g., from STANNOL KS10 SnAg 3,0/0,5 Cu0,7 (or similar) (Made in Germany). The X2210 solder wire contains a **rosin-free** flux with synthetic resins. Version 1.64 is the product: https://www.conrad.de/de/p/stannol-ks10-loetdraht-sn96-5-ag3-0-cu0-5-cu0-7-600-g-1-mm-5400742.html

Alternatively, a **soldering fume extractor**.

Installing soldering fume through the mouth and nose is harmful to health. Therefore, please ensure that the workshop fumes are effectively removed from the soldering joints and that the room is well ventilated. Alternatively, a fume extractor or work in the open air if possible. Soldering fumes can be harmful to health. Therefore, please ensure that the workshop is well ventilated. Avoid inhaling the soldering fumes. A highly recommended soldering fume extraction system is the ZeroSmog Stretch Arm Mono. It's not a bargain, but it's very effective. Source: Link to the product: https://www.lamellen-werkzeuge.de/produkte/loetrauchabsaugung_serienmeg_stretch_pro-071044

The soldering iron should have a power rating of at least 50 W, an adjustable temperature and a soldering tip in the range of 270°C to a maximum of 370°C. Cleaning the soldering tip with a sponge moist and a sponge (filled with water) is necessary to remove any scale residue from the soldering tip.

3) Work preparation – assembly and soldering

We recommend the following **electronic tools and accessories**:

- Electronic side cutters to shorten the cover pliers
- Small central or Philips screwdriver
- Mini-key (Allen) 2mm (SW2/0.05 screws)
- 5.5mm (SV) socket wrench or 5.5mm open-end wrench
- Soldering tin holder with a storage tray for 1 to 2 mm tools in the front panel
- Solder wire powder 0.5
- Desoldering pump or desoldering copper wire 1.5mm wide as a spare
- Solder wire 0.7 mm to 1 mm, lead-free, e.g. Stannol KS10 SnAg 3,0/0,5 Cu0,7 and, if necessary, to measure the metal film resistors
- a small USB keyboard with cable (for the FORMAL)
- A heat-resistant silicone mat (min. 20% A4 format)
- Tweezers for holding components in place
- A "third hand" or electronic vice (e.g. Bernstein Spyroflex tools 5-203 ESD) or similar
- Source / Link to the product: https://www.bernstein-werkzeuge.de/produkte/produktdetails/5-203-elektronik-und-feinmechaniker-kombination-vario-4-in-1

4) GND – Soldering of GND pads and areas

The **GND pour** copper pours must first be distributed for a clean soldering joint, so, if possible, the GND areas on the component side at the same time and add a very small amount of solder. The soldering is "good" when the solder has flowed well into the GND pad.

A quick tip: In general, less content is more. The larger the solder ball, the more likely it is to have a cold solder joint! The fact that the GND pins are harder to solder than the other pins is due to the copper surfaces on both sides of the GND and their high heat dissipation on the circuit board. However, the electrical advantage of good heat distribution on the soldering and component sides outweighs this.

5) Preparation and sorting of components

Note:

We assume that you already own the NAVPANEL V3, as this is a hardware extension for the NAVPANEL V3 mainboard from version V3.RR-rc5-01 or newer.

Sort components by type:

Resistors, capacitors, electrolytic capacitors, diodes, coils, ICs, LEDs, DIP switches, USB-A sockets, other plugs and sockets. Use small containers or trays for this. Label each container clearly. Check the components for damage. Discard any damaged components. Use a multimeter to check the values of resistors and capacitors. Use a magnifying glass for small components.

Resistance determination using the color code table

The resistors are labeled on the paper tape, like any supply metal film resistors with 1% and 0.1% tolerances. The color coding table can be found here: https://www.elektronik-kompendium.de/sites/bau/1109051.htm

The color code table

Before you start determining the resistance, you have to count how many rainbow rings are labeled on the resistor. Resistors with four rainbow rings are the most common. They have a tolerance of 5% or 10%. Resistors with five rainbow rings have a precision value that is labelled in the color code precisely. Then you have to determine what ring it is the last one. This is the tolerance ring. Which indicates how high the determined resistance value can be. Resistors with four rainbow rings have a 5% or 10% tolerance. The 5% ring is gold, the 10% ring is silver. The first ring is the one that is closest to the edge. The ring after it is the one that is next to it. The ring after that is the one that is next to it. This is the tolerance ring. Then you start putting the resistance value together from the beginning. The colors have specific values. The first and second rings determine the resistance number or ring like a decimal number. The third ring acts as a multiplier. It determines how high the resistance value is. The fourth ring is the tolerance ring, which determines the tolerance of the resistance (how far the resistance can deviate from the nominal value).

Examples: the NAVPANEL V3 DIY kit with 2 front panels

Resistance determination using the color code table

6) Equipping the Pedal-USB Breakout Board

Please decide now whether the pedal USB breakout should be configured for desktop or Eurorack!

- The Eurorack version requires the **DIP front panel Pedal-USB**, otherwise the connectors and PWR-LED are missing!
- The **Eurorack version omits** the following components:

- LED1 PWR 5V
- LED2 Activity (at LED1)
- R1, R2 TRS connectors 6.8mm 1/4" (rear jacket connection)
- X04 USB-HOST and X04 USB-A (USB ports at the rear)
- X19 16-pin eurorack power (power is supplied via the mainboard).

For the **desktop version**, proceed as described from **point 7**.

IMPORTANT! The X19 16-pin eurorack header is **not used in the desktop or Eurorack version** (power is supplied via the mainboard).

Assembly metal film resistors R1, electrolytic capacitor C2, ceramic capacitor C1

For display only: Assembly of the X19 header for the Eurorack power supply **IMPORTANT!** The X19 16-pin angled header is not assembled (power is supplied via the mainboard).

Assembly of JP1, JP2, JP3 (Jumper female connector) **IMPORTANT!** The X19 16-pin angled header is not assembled (the power supply is provided by the mainboard).

7) Assembly of components resistors, electrolytic capacitors, ceramic capacitors

Due to its design, the Pedal-USB breakout board is plugged into the back of the mainboard (solder side). Components are normally mounted on the component side. All components are then mounted and soldered according to the plan.

- Bolt four metal hex washers (all diameter) to the paper layer)
- Metal film resistors
- Red CO Hahn 100kΩ and CO Elko 100µF/16V

Assembly metal film resistors R1, electrolytic capacitor C2, ceramic capacitor C1

For display only: Assembly of the X19 header for the Eurorack power supply **IMPORTANT!** The X19 16-pin angled header is not assembled (power is supplied via the mainboard).

Assembly of JP1, JP2, JP3 (Jumper female connector) **IMPORTANT!** The X19 16-pin angled header is not assembled (the power supply is provided by the mainboard).

8) Component placement on the Eurorack 16-pin X19 / USB-C / 16-pin connector strip X21

IMPORTANT! The X19 16-pin angled header is **not** installed (power is supplied via the mainboard, only +5V and GND are required).

The 16-pin (2x8-pin) connector strip X21 is for the connection to the **pedal-USB front panel**, which is connected with the ribbon cable (20cm).

The X-CON-C connector is only required with a USB-C PD charger. Do not request, as the power is already supplied via the NAVPANEL V3 mainboard.

Press USB, Jumper JP4 normal profile socket strip 1x2-pin, 1-2 = CLOCK OUT, JP1 3-4 = SPDIF OUT

Press USB, Jumper JP4 normal profile socket strip 1x2-pin, JP1 1-2 = CLOCK OUT, JP1 3-4 = SPDIF OUT Press USB, Jumper JP4 and P3 front panel JP3 2-3 = CLOCK OUT DFF

Overview: Front panel for pedals and USB, jumpers, male and female headers. Connect the 4-pin connection cable for the USB-A/B port installed on the DIP front panel to the X19 Since the polarity is correct, Pin 1 = 5V, GND, Pin 4 = GND.

9) Assembly of the TB/TRS sockets / USB-A and / USB-HOST / DIP switch

Now the 6.3mm (1/4") TRS jacks, the USB jacks and the DIP switch DS1 are soldered in.

- Solder USB-A and USB-HOST (print outlines).
- Solder the SIXZ DIPS switch for the pedal-configuration.
- Solder the 6.3mm TRS sockets for the pedal connection. **DO NOT use in EURORACK and DIP front panels!**
- Check briefly here the 5mm LED: PWR for and ensure correct polarity. The **long leg is the + anode**. The **+ anode of the LED** is marked on the circuit board.

Only USB-A and USB-HOST

Only TRS

Only DIP switch

10) Assembly of the TB/TRS sockets / USB-A and / USB-HOST / DIP switch

Now the 6.3mm (1/4") TRS jacks, the USB jacks and the DIP switch DS1 are soldered in.

- Solder USB-A and USB-HOST (print outlines).
- Solder the SIXZ DIPS switch for the pedal-configuration.
- Solder the 6.3mm TRS sockets for the pedal connection. **DO NOT use in EURORACK and DIP front panels!**
- Check briefly here the 5mm LED: PWR for and ensure correct polarity. The **long leg is the + anode**. The **+ anode of the LED** is marked on the circuit board.

Only USB-A and USB-HOST

Only TRS

Only DIP switch

11) Equipping the long connector strips

Adaptation between pedal-USB breakout and the Navipanel mainboard with **special 16mm long connector strip** in

- 4-pin pins X11 and X12 (volume and switches)
- 10-Pol pins X9 (power supply)
- 16-Pol pins X21 (USB-C to the Navipanel Mainboard)
- 4-Pol pins X10 (MIDI IN and MIDI OUT via Pedal-Board)

Now loosen the M3x40mm ISO7380-1 mounting screws located on the back of the mainboard and screw them through the M3x10 studs for mounting the connector strips **without the 2.5mm washers** to the Mainboard ISO7380-1 mounting screws and tighten them with the mainboard. The connector strips will then sit tightly in the socket strips on the mainboard, and everything will fit. Solder all connector strips on the pedal USB breakout board with the mainboard plugged in and screwed in place.

Only X21 socket connector X19 for Eurorack power supply **do not use X19 !**, bottom right Socket connector X21 connection to the **DIP front panel pedal USB**

Complete desktop setup:
USB-A front, USB-A / both TRS 6.35mm pedal jacks, DIPS switch SIXZ

Example shows: PEDAL-USB PCB with the two connector and TRS 6.35mm for PEDAL Volume.

USB-A/B X4D + 4-pin 90° connector for cable to the 6HP front panel connector
TRS 6.35mm for PEDAL Volume and PEDAL Switch on the 6HP front panel connector
Note: Only one of the two USB ports is provided in the 6HP front panel!

12) Check the pedal USB breakout board assembly

Before inserting the end of the assembly: Check visually! Are any components left racing? Are the M3x10 PC-Fit hex bolts and the 3.2mm washers as spacers. These should then be inserted onto the threaded rods and screwed into the mainboard. Are the connectors for the mainboard - power USB, TRS all slightly recessed the distance between the two boards. Now, all solder joints will be checked again and re-soldered if necessary.

- Check components for correct position ...
- Pay attention to the correct polarity of the LED
- Are all long power strips in the correct positions?

The Pedal-USB breakout board components side / socket side should now look like this:

Mirrored with Mirror-CV **SYSTEM SETTINGS** (assembly shows NAVPANEL CV demo device)

Mirrored with Mirror-CV **External Test** (assembly shows NAVPANEL V3 demo device)

Mirrored with Mirror-CV **SYSTEM SETTINGS** (assembly shows NAVPANEL V3 demo device)

Mirrored with Mirror-CV **External Test** (assembly shows NAVPANEL V3 demo device)

13) It's almost done!

- The white cable on the mainboard is **X1 PWR 12V**
- Then the first assembly can take place ... restart the NAVPANEL V3 front panel.
- The white cable on the mainboard is **X1 PWR 5V**
- Connect the volume pedal and sustain pedal. The 3.5mm TRS jacks on the mainboard's front panel for SUSTAIN and VOL PEDAL are wired in parallel with the 6.35mm TRS jacks on the M3D to CV / Pedal-USB breakout board.
- Log connect to CLOCK OUT / CLOCK IN to an external synthesizer or Microbrute) and test.
- The software version 1.0.0.5 (under **Downloads**) of @pocketmagic has implemented the necessary functions.
- Test the following functions/connections:
- CLOCK OUT DFF (pronounced: expander)
- SUSTAIN PEDAL IN (5V)
- VOLUME PEDAL IN (3.3V)

Pedal-USB breakout board view from the right with mainboard (desktop and Eurorack version)
Note: please set the DIPS-Switch SW2 (bottom right in the photo) as described above in point 13.1 .

Pedal-USB breakout board view from the left and mainboard (desktop and Eurorack version) with 8HP front panel for **Pedal-USB**


14) Test environment with 4 Microdexed / USB devices / Midi CC-Fader V3

We tested in the following configuration:

Test environment: AKAI MPCmini, ARTURIA MiniLab3 and 1x Microdexed NAVIPANEL V2 4MS – 3x Microdexed NAVIPANEL V3 and **MIDI FADER V3** .



Test environment: AKAI MPCmini, ARTURIA MiniLab3 and 1x Microdexed NAVIPANEL V2 4MS – 3x Microdexed NAVIPANEL V3 and **MIDI FADER V3** . We tested the following configuration with the USB hub 1-4 on 3 of 4 possible USB-A ports:



- AKAI MPC mini (Midi via USB)
- AKAI MPD 218 (Midi via USB)
- ARTURIA MiniLab3 (Midi via TRS MIDI IN)

The total current consumption was in the range of 390mA – 410mA, so still well under 500mA.

The entire setup is powered by the **Behringer Eurorack 6in** with an external 9Vdc/4 power supply and USB plug-in power supplies.

A notice:

If the black push button **S3 USB PWR is not set to " ON "** (USB ports 1-4 of the UK USB hub cannot be used, e.g., for USB MIDI data transfer. In general, using USB for audio and MIDI in a tricky issue. Many cheap (and even have 4 A!) under 3 and 4 channel of the required 5 USB. Another issue is potential noise on the audio outputs when using USB audio and/or audio outputs. Be cautious. But both external +5V and USB on PC or MAC are not a problem.

IMPORTANT: The jumper switch of the NAVIPANEL V3, **S1 PWR** (only cap) must then be set to " **OFF" when using external power supply** .

15) External power supply and Eurorack NAVIPANEL and options

An external 5V power supply (2?), either via the 5V1A DC connector or via an external USB) 5V power adapter, is also helpful to prevent any noise or hum. The new version, released in April 2025, now also includes a USB-C power connector (JP1, POWER-IN).

IMPORTANT! The X19.16-pin angled header on the **Midi-to-CV breakout board** and **Pedal-USB breakout board is not equipped** (the power supply is via the mainboard; only +5V and GND are used). The current power supply only makes sense if the USB PC or MAC connection is not used for data transfer. So decentralized without a notebook or similar, e.g. during live performance. But both external +5V and USB on PC or MAC work.

IMPORTANT: The power switch of the NAVIPANEL V3, **S1 PWR** (only cap) must then be set to " **OFF" when using external power supply** .

16) Additional hardware functions and sockets

The **MIDI OUT socket** is fully functional and integrated into the Microdexed software. It delivers a 44 kHz/16-bit digital signal to a 3.5 mm jack (TS) connector (SPDIF OUT). For connection, a standard SPDIF cable for digital audio transmits 3.5 mm TRS jack to an RCA connector is required.

The **CLOCK OUT** output (same jack as SPDIF OUT) is fully integrated into the current software. Two software versions are available for operation with **SPDIF** or **CLOCK OUT** (current version under " Downloads "):

The **TRS jacks VOLUME/MIDI-CH/dr, CLOCK-/R, and SUSTAIN PEDAL/GATE-/R** are hardware and software functional.
Information on voltage levels can be found under " Technical Specifications ".


The functionality and use of the USB HOST, USB-1, USB-2, USB-3, and the USB-A port (USB-HOST) on the rear panel are described in section 11. The Teensy 4.1 micro-USB port can be switched **ON/OFF using S1 PWR** and is no longer accessible from the front panel.

For hardware support, please contact:
thomas.t.ehrlich, info@musikanalogmodule.net or **@musikanalogmodule** on Lescon (https://lescon.gg/XzYKPWGF) .

For questions about the Microdexed software, please contact:
Mark Kostowski aka @positivegrowth (https://discord.gg/XzYKPWGF) .

17) The finished device NAVIPANEL V3 for Microdexed with the Pedal-USB option


Photos with different device views:




Device variant front **Eurorack 3U/32HP** with 8HP front panel pedal USB




Device variant rear **Eurorack 3U/32HP** with 8HP front panel pedal USB



Case variant rear right **Eurorack 3U/32HP** with 8HP front panel pedal USB



Device variant rear left **Eurorack 3U/32HP** with 8HP front panel pedal USB



Device variant solder side **Eurorack 3U/32HP** with 8HP front panel pedal USB

18) Appendix A.

As of: September 15 2025

Sources / Links / Product recommendations

- Bernstein ball joint foot holder 1 (via the product):
  https://www.bernstein-werkzeuge.de/produktdetails/8-250-and-kugelgelenk-kombination-vario-8-dig
- Solder / Link to the product:
  https://www.conrad.de/de/p/stannol-ks1715-loetzinn-bleifrei-spule-sn99-cu0-7-inhalt-100-g-1-stueck-2887472.html
- Soldering extraction system / Link to the product:
  https://www.reichelt.de/de/de/shop/produkt/werkzeug_und_zubehoer/loetzubehoer/loetrauchabsaugung_aerosmog_shield_pro-371044
- USB host adapter from pjrc.com / Link to product:
  https://www.pjrc.com/store/adapter_usb_host_t36.html
- Resistor color code table: https://www.elektronik-kompendium.de/sites/bau/1109301.htm
- Current original manual from Microdexed (github.com): https://codeberg.org/positivegrowth/Microdexed-touch/releases
- Current original manual from Microdexed (github.com):
  https://codeberg.org/positivegrowth/Microdexed-touch/src/branch/main/doc/MicroDexed-touch-manual.pdf
- diy usb c female breakout: https://www.pjrc.com/teensy/loader.html
- Discord Channel @positivegrowth: https://discord.gg/XzYKPWGF
- Link to Web Remote Console: https://positivegrowth.codeberg.page/
- ARCELI USB Isolator Module, Industrial Isolator Protection Against Audio Noise, 1500V Digital Module:
  https://www.amazon.de/dp/B07BJD8S7D?ref=ppx_yo2ov_dt_b_fed_asin_title
- Midi cable not pack of 3 classification TYPE A
  https://www.thomann.de/de/serfaco_trs_midi_cable_a.htm
- Midi cable grey 3-pack classification TYPE B
  https://www.thomann.de/de/serfaco_trs_midi_cable_b.htm
- 4MS pod32 cabinet 32HP (powered):
  https://www.thomann.de/de/4ms_pod32_powered.htm
- 4MS pod32 enclosure 32HP (powered) (=subcabinet set):
- 4MS pod32 cabinet 32HP (unpowered) (**special purchase via Thomann**)
  https://www.thomann.de/de/4ms.html
- Power supply for Eurorack enclosure 4MS pod32 / maximum output power: 15 V / 3 A 45W
  https://www.thomann.de/de/mow_power_brick_45w.htm
- 3D case / housing 32HP for NAVIPANEL V1 from mainboard v36 (musikanmoer.net)
- 3D case / housing 32TE for NAVIPANEL V1 from mainboard v36 (musikanmoer.net)
- 3D case / housing 32HP for NAVIPANEL V2 from mainboard v541 (musikanmoer.net)
- USB C Charge Power Supply Breakout UK (Amazon):
  https://www.amazon.de/dp/B0CQ6CFYQV?ref=ppx_yo2ov_dt_b_fed_asin_title

19) Appendix B. Credit

Contributors:

Mark Kostowski aka @positivegrowth (https://discord.gg/XzYKPWGF)
for the excellent software and hardware base.

Holger Wirtz for the original port of the Dexed FC(Arduino) OS to the Teensy 4.1 MICRODEXED – Microcontroller

Thomas Ehrlich https://musikanalogmodule.net/ Hardware development and panel / PCB design

Nicole Effertz - https://designsignsprung.de/ for her patience with the seemingly endless proofreading of the assembly instructions and technical documentation.

20) Appendix C.

License and copyright

Creative Commons Attribution-NonCommercial 4.0 International (CC BY-NC 4.0)

You are free to:

Share – to copy and redistribute the material in any medium or format. Adapt – to remix, transform, and build upon the material.

The licensor cannot revoke these freedoms as long as you comply with the license terms.

Under the following conditions:

Attribution – You must appropriately credit the author, provide a link to the license, and indicate any changes. This applies, but not in a way that suggests the licensor endorses you or your use.

Non-commercial – You may not use the material **for commercial purposes** .

No further restrictions – You may not apply any legal provisions or technological measures that legally prevent others from performing the acts permitted by the license.

Notes:
You are not required to comply with the License for any portion of the Material that is in the public domain or whose use is permitted by an applicable exception or limitation.

No warranties are provided. The license may not grant you all the permissions necessary for your intended use. For example, other rights such as publicity, privacy, or moral rights may restrict your use of the material.

The full license text can be found at:
https://creativecommons.org/licenses/by-nc/4.0/legalcode

Project: NAVIPANEL V3 for Microdexed
Author: Thomas Ehrlich / Musikanalogmodule / www.musikanalogmodule.net
Software: Mark Kostowski (Software Microdexed Version 1.6.4 / 6.6.6)
Author: info@musikanalogmodule.net
Date: September 22, 2025
Version: V.1.0.2E (this document)
License: Creative Commons Attribution – Non-Commercial 4.0 International (CC BY- NC 4.0)

21) Appendix D.

Technical data Pedal-USB Breakout / September 19, 2025

Pedal USB for Microdexed Navipanel Mainboard from V3-R05-v541

Print PDF

NAVIPANEL V3 Pedal USB	Date: September 19, 2025	Technical data sheet	ID-(BOM)	X21 Pills
01) Modular rack 3U / 32HP / Dimensions (W x L x H): 153x127x33mm		Eurorack	optional... (*)	
02) 3d printed Desktop Case 3HE / 32TE / Dimensions (W x L x H): 159x154x38mm		Desktop	optional... (*)	
03) Desktop aluminum case 4585 pod32 powered / Dimensions (W x L x H): 166x150x40mm		Metal housing	optional... (*)	
04) power supply (USB-C Power Supply Breakout and 4585 4585 Power Brick)		Power supply	optional... (*)	
05) 16-pin box connector with 20cm ribbon cable		for modular (+5V)	Eurorack cable	
06) 16-pin box connector with 15cm ribbon cable		for 8HP Eurorack front panel	Eurorack cable	1-16
08) Internal / external supply for USB hub		switchable	included	
07) from USB-HOST Hub Port 4, 1x USB-A if which are NOT in the front panel		from active USB hub U6	U6 (Mainboard)	
09) 1x USB-A connectors on the back via 4-pin connector		USB-A 2.0	X38 HOST-A/B	
09) alternative CLOCK OUT TRS 3.5mm (5/5) optocouplers		modular connection	TRS 3.5mm	(5) Z1
10) PEDAL Volume Input 1/4 inch TRS +3.3V (Digital GND) (Eurorack)		modular connection	TRS 6.35mm	6/4
11) CV IN / alternative (5-VOC / 0-10VDC input (protected with suppressor diodes)		modular connection	TRS 6.35mm	6/4
12) PEDAL SUSTAIN IN + SUSTAIN 5V+3.3V+ LOW/HIGH (Backside)		modular connection	TRS 6.35mm	12/10
13) GATE IN + PEDAL SUSTAIN IN 5V+3.3V+ LOW/HIGH		modular connection	TRS 6.35mm	12/10
14) LED5 5V Power (Backside)		LED 3mm low current RED	LED1	14 (VCC +5V)
15) Expansion connector 16pin for ETE front panel with Eurorack compatible		MIDI to CV / Pedals / LEDs	X21	1/28 (GND)
15) Expansion connector 16-pin				3 (GND)
15) Expansion connector 16-pin				16 (VDD +12V)
Note 1) The technical data apply from motherboard version and the Navipanel V3 mainboard is necessary!			V3-R05-v541, July 02, 2025	
Note 2") only on the smaller pedal / USB PCB version (PEDAL-USB-Breakout-Board) without Midi to CV and Gate OUT			V3-R05-v472, July 02, 2025	

Generated by wpDataTables

22) Appendix E.

BOM Part list for NAVIPANEL Pedal-USB

Pedal / USB PJ2-R3-v541 / 19-21-2025

Print PDF

Show entries

Seek

part	Value	Detailed Description
C1	100nF	CAPACITOR
C2	10uF tantalum/16V	Capacitor Polarised - Generic
EUROrack_CABLE	Flatcable_16pol_20cm	Flatcable, 16pol, 20cm
H1	STANDOFF_M3X10mm_1/4	STANDOFF_M3X10mm_1/4
H2	STANDOFF_M3X10mm_1/4	STANDOFF_M3X10mm_1/4
H3	STANDOFF_M3X10mm_1/4	STANDOFF_M3X10mm_1/4
H3S+H5	8x_WASHER_DIN125A_3.2mm_for_distance	8x_WASHER_DIN125A_3.2mm_for_distance
H4	STANDOFF_M3X10mm_1/4	STANDOFF_M3X10mm_1/4
H4S+H2	3x_NUTS_DIN127_M3_for_Standoff M3x10mm	3x_NUTS_DIN127_M3_for_Standoff M3x10mm
H5	STANDOFF_M3X10mm_1/4	STANDOFF_M3X10mm_1/4
H6S+H5S	8x_SCREWS_WSx8mm_ISO7380-1_V2A	8x_SCREWS_WSx8mm_ISO7380-1_V2A
H6	STANDOFF_M3X10mm_1/4	STANDOFF_M3X10mm_1/4
JP1	CLK/SPDIF-OUT	PIN HEADER 1x3-pin jumper
JP2	SW_CKL/SPDIF-OUT	PIN HEADER 1x3-pin jumper
JP8	CLK-SPDIF-OUT	FEMALE HEADER 3-pin
JUMPER	JUMPER 2-pin	2x JUMPER 2-pin
LED1/PWR	3mm_red_low_current	3mm_red_low_current
PCB_BREAKOUT	MIDI_TO_CV_V3-R05-v61_19-09-2025	MIDI_TO_CV_V3-R05-v61_19-09-2025
R1	1K	RESISTOR, European symbol
SW2	DIP6-SW2-PEDALS	6-position DIP switch
USB-A-CABLE	1x USB4_Cable_20cm_4pin	1x USB4_Cable_20cm_4pin
X-USB-C	PIN2+NC	PIN HEADER 2-pin RM5.08
X1	MIDI/VE-1-ALI	Phone Connectors 1/4 JACK STEREO SW SLIM-FULL THREAD NISE*
X14	SUST-PEDAL	LONG PIN HEADER 1x3pin 14mm
X15	VOL PEDAL	LONG PIN HEADER 1x3pin 14mm
X19 *	EUROrACK 90° PWR (*) (to not solder X19)	HARTING 16-pin 90°
X2	MIDI/VF-1-ALI	Phone Connectors 1/4 JACK STEREO SW SLIM-FULL THREAD NISE*
X21	Expa.Board ETE 90° ETE front panel	HARTING 16-pin 90°
X4A	USB4-A4	DIP-USB-A-TYPE-FMAL(=2P-2-S-90D)
X4B	USB4-A4	LONG PIN HEADER 1x4pin 14mm
X4B1	USB4-A4	PIN HEADER 1x4pin 90°
X5	USB HOST	LONG PIN HEADER 1x4pin 14mm
X5A	USB HOST	DIP-USB-A-TYPE-FMAL(=2P-2-S-90D)
X5B	USB HOST	PIN HEADER 1x4pin 90°
X8	VCC Breakout	LONG PIN HEADER 2x5-pin 14mm

1 to 8 of 8 entries

Generated by wpDataTables

MUSIKANOMORE
MUSIC - SOUND - PCB - PANELS

DELIVERY | PAYMENT

All prices are in euros (€) and include VAT, plus shipping costs. Subject to change without notice. Product images may vary. While stocks last. Ships from Germany. Germany, Austria, and rest of EU countries: Switzerland, Great Britain, the USA, and Canada.

Canada are available upon request. The crossed-out prices correspond to the previous prices in our shop.
Last updated: August 28, 2025

PAYMENT OPTIONS

VISA PayPal

NAVIGATION

- Home
- Blog
- Shop
- My Account
- Shopping cart
- Checkout
- Shipping methods
- Payment methods
- Return policy
- Authenticity of reviews
- About musikanmoer

DOWNLOADS | LINKS

- All downloads
- Interesting links
- Construction instructions NAVIPANEL V3/ V2.1-DE
- Construction instructions NAVIPANEL V2/ V6.5-DE
- Assembly instructions MIDI to CV PEDAL-USB V1.0-DE
- Assembly instructions PEDAL-USB V1.0-DE
- Assembly instructions for the 8HP front panel MIDI-to-CV/ V1.0-DE
- Assembly instructions for the 8HP front panel PEDAL-USB/ V1.0-DE
- midi_FSWAM-CAP_TOUCH-MINI-CV 1.5 S R
- midi_FSWAM-CAP_TOUCH-MINI-APC- 1 S R
- midi_FSWAM-CAP_TOUCH-MINI_8PDF- 1 S R
- MicroDexed touch manual version 2.57.pdf
- codeberg.org/positivegrowth/Microdexed-touch
- Mini Microdexed MIDI™ encoder

NAVIPANEL V3 | NAVIBUTTON V2

EURORACK FRONT PANELS



FOLLOW US ON...

f

Shopkeeper © 2025 - All rights reserved - Web design by shopkeeper.org

23) Appendix F

Changes:

Changelog: from May 25, 2025 to July 2, 2025

Pedal USB – PCB version **V3-R01-v541** from May 25, 2025

- USB Host (X5) 5-pin and USB A4 (X4B1) with 90° 4-pin connector strips added for connection cables to the 8HP front panels

Pedal USB – PCB version **V3-R02-v73** from July 2nd, 2025

- Parts lists as subpages for components that are included in the scope of delivery but are not directly located on the PCBs

24) Appendix F

Changes:

Changelog: from 02.07.2025

Pedal USB – PCB version **V3-R03-v54** from September 21, 2025

- Parts lists as subpages for components that are included in the scope of delivery but are not directly located on the PCBs
- minimal corrections to the PCB silkering
- 3 mounting holes for securing the 4-pin USB adapter cable with a cable tie