Captured at: 24/09/2020 19:18 URL: https://www.musikmanufaktur.net/bauanleitung-ihr-frontpanel-pedal-usb-v1-0-die/

ASSEMBLY INSTRUCTIONS IHP FRONT PANEL PEDAL-USB V1.5-DE

Assembly instructions / Documentation / IHP front panel PEDAL-USB

Technical Documentation V1.0 DE / Status: 23.09.2025

- for PCB version mainboard V3+MS+AVR1 from July 2025
- for PCB size mainboard V3+MS+AVR1 from July 2025
- for PCB 9x6 to C-Pedal-USB-Breakout still from September 21, 2020
- for PCB 9x6 to C-Pedal-USB-Breakout still from May 28th, 2020
- for PCB 9x6 to PEDAL-USB-Platine-V1.0 from May 28th, 2020
- Technical-data-IHP-Frontpanel-Pedal-USB-Expander-22.09.05 (PDF)
- IHP-Front-Aufkleber-PEDAL-USB (PDF)

Table of contents

1. Disclaimer
2. Necessary recommendations and tips
3. Work preparation - assembly and soldering
4. GND - Soldering GND pads and areas
5. Assembly of the main boards
6. Assembly of the IHP-front panel-USB-breakout board
7. Assembly of the components sockets, Kerko, TS-socket
8. Component placement Eurorack_M, 16-pin X2 / 16-pin connector strip X1
9. Assembly of the TS/TRS sockets / USB-A1 / S-PHR / S2-Polarizer / X3-X5
10. Commissioning / Functional test
11. Test environment with 4 Mini-Breakout / USB-Micro / Midi-DS Sockets
12. External power supply and Buchsonit
13. Software installation / Setup / Update
14. The Firmware-Service MAXPANEL V2 for Windows® with the Pedal-USB option
15. Appendix A: Sources / Links / Product Recommendations
16. Appendix B: FAQ
17. Appendix C: Licenses and Copyright
18. Appendix D: Technical Specifications Pedal USB Breakout
19. Appendix E: BOM parts list for MAINPANEL Pedal-USB
20. Appendix F: Changes since 23 May 2025
21. Appendix G: Changes since 03.07.2024



1) Disclaimer

Before you begin with the kit and assembly, we have some legal information for you. Please read the disclaimer carefully. Thank you for your understanding. The right of withdrawal and return expires as soon as the packaging has been opened. We cannot guarantee the included circuit boards or populated the front panels. The DIY kit can only be returned in a in an unused condition. The buyer is responsible for the return shipping costs. The warranty is limited to the components included in the DIY kit. Any warranty claims will be passed on to our suppliers (supply chain verification) in accordance with product liability law. We are not liable for damage to other devices or consequential damage, such as recording failures or loss of recordings due to the use of our products or the failure of one of our components.

Please note that Zeiegnungsnung und Thomas Effenbg (Musikmanufaktur) are free from any legal claims that may result from injuries caused by the assembly, soldering and improper use of the MAXPANEL V2 Mini-Breakout, as well as from handling damage caused by initiating soldering fumes.

This project requires **good soldering skills** and a basic degree of **soldering experience**, as well as **basic electronics knowledge**. Every electronics project depends on the tools and the care taken when soldering, involving ESD soldering and working DIN) (ground) system rules. Soldering irons and pliers are the most common cause of failures in electronics. The same applies to unwanted solder bridges, e.g., between two solder pads.

One important aspect of handling electronic components is the **ESD treatment** of semiconductor devices such as ICs, FDDNE, the Teensy 4.1, etc. We know that not every electronics hobbyist or musician has an ESD workbench, grounding wrist straps, ESD mats, ionizers, or discharge spar some therefore recommend the following tips:

Tip: To avoid damage to the semiconductors, if possible, touch something metallically connected, e.g. a radiator, before touching semiconductors in order to discharge static electricity.

Tip: Before touching the components, touch the ground connection of any 5 V USB power supply (optionally with USB-C power), and the 16-pin Eurorack power supply (+5V and GND). Please note that the 16-pin and USB power supply work only well, however, the spreading electric laundry on the power cable's perimeters.

A power supply with **5 V LPS batteries** is **not technically possible**, as the USB devices, the USB bus-hub, and the analog components require 5V DC. Should the Raspberry Pi Zero and with LPS batteries be used, the recommended way is to use the Raspberry Pi Zero only for the firmware updates and not to test the software for any technical defects in the MAXPANEL V2 for Mini-breakout or other technical devices.

LiPo 3.7V batteries are not safe to **handle and should only be used by professionals with appropriate electronics knowledge.**

2) Soldering recommendations and tips

Use only **lead-free solder** with a diameter of 0.7 mm - 1.0 mm, e.g., from STANNOL KE510 Sn99,3Cu0,7 sn+0,3 mm (Made in Germany). The KE510 solder wire contains a **rosin-free** flux with synthetic resins. Order here: https://www.reichelt.de/de/de/shop/produkt/elektronik/107/loetzinn/loetzinn_sparpreis_stannol_sn99_cu07_0_5_mm_1000g-sn99cu07-0-5-1000g-stannol-kerko-1000g-sn99cu07-0-5-1000g-stannol-kerko-1000g-sn99cu07-0-5-1000g-stannol-kerko-

Pedal-USB breakout board, view from the left and mainboard (desktop and Eurorack version) with **BHP front panel for Pedal-USB**

11) Test environment with 4 Microdeved / USB devices / Midi CC-Fader V3

We tested in the following configuration:

Test environment: AKAI MPCmini, ARTURIA MiniLab3, and 1x Microdevked NAVIPANEL V2 AMS , 3x Microdevked NAVIPANEL V1 and **MIDI FADER V3** . For testing CLOCK IN/OUT or the CV outputs and GATE OUT, we also have analog modular devices in Eurorack format such as VCO, ADSR, VCF, and VCA, as well as the necessary mixes and stereo mixers in the hot setup.

Test environment: AKAI MPCmini, ARTURIA MiniLab3 and 1x Microdevked NAVIPANEL V2 AMS , 3x Microdevked NAVIPANEL V1 and **MIDI FADER V3** .

The entire setup is powered by the **Behringer Eurorack 8x** with an external 90VA power supply and USB plug-in power supplies.

AKAI MPCmini via USB host on the Microdevked **NAVIPANEL V2 AMS**

Test environment : We tested the following configuration with the USB hub 1.4 on 3 of 3 possible USB-A ports

- AKAI MPC mini (Midi via USB)
- AKAI MPD 218 (Midi via USB)
- ARTURIA MiniLab3 (Midi via TRS MIDI IN)

The total current consumption was in the range of 380mA – 410mA, so still well under 500mA.

A notice:

The hub must be built for 5V USB PWR in not set to " ON " USB ports 1-4 of the UR USB hub cannot be used, e.g., for USB MIDI data transfer. In general, using USB for audio and MIDI is a tricky issue. You can't even have 4 AV under load instead of the required 5V USB). Under these circumstances, a power failure on the audio outputs when using USB audio and/or audio via the modules. Complete USB isolation is very helpful for eliminating ground loops and USB "interference." We use several of these USB isolation modules in our studio.
Link to the product: AXCELL USB Isolator Module, Industrial Isolator Protection Against Audio Noise, 1500V
Digital Photo: https://www.amazon.de/dp/B07L6JR6TP?tag=m_pcl3m_dt_fl_fwd_em_00e

12) External power supply and Eurorack NAVIPANEL and options

An external 5V power supply (≥1.5A) from the 48-0V DC connector or via an external (USB) 5V power adapter, is also helpful to prevent any noise or hum. The new version, released in April 2025, now also includes a USB-C power connector (JST_PH(B2B-PH).

IMPORTANT! The **X18** 16-pin angled box connector on the Midi&Co breakout board and Pedal-USB breakout board is **not populated** (the power supply to the mainboard, only +5V and GND are used). The external power supply does not share the +5V of the USB PC or MAC connection is not used for data transfer. So disconnect when not in operation! Also, during live performances. But not between +5V and USB on PC or MAC also work.

IMPORTANT! The power switch of the NAVIPANEL V2, **S1 PWR** (white cap) must then be set to " **OFF" when using external power supply** .

13) Additional hardware functions and sockets

The **SPDIF OUT output** is fully functional and integrated into the software. It delivers a 44 kHz/16bit digital signal to the 3.5 mm jack (TS) connector (SPDIF OUT). For connection, a standard SPDIF cable adapter from a mono 3.5 mm TRS jack to an RCA connector is required.

CLOCK OUT output (same jack as SPDIF OUT) is fully integrated into the current software. Two software versions are available for operation with **SPDIF** or **CLOCK OUT** (current version under " Downloads ").

The **TRS jacks VOLUME PEDAL-CV-IN, CLICK-IN, and SUSTAIN PEDAL-GATE-IN** are hardware and software functional. Information on voltage levels can be found under " Technical Specifications ."

The functionality and use of the USB HOST, USB-1, USB-2, USB-3, and the USB port (USB-HOST) on the rear panel are described in section **11.** The Teensy 4.1 micro-USB port can be switched **ON/OFF using S1 PWR** next to the power switch.

For hardware support, please contact:
Thomas Eberle, **info@musikanalogue.net** or **@musikanalogue** on Discord (https://discord.gg/N7XYP6SqP).

For questions about the Microdevked software, please contact:
Mark Kvitsveet aka @pyrofyter (https://discord.gg/N7XYP6SqP)

14) The finished device NAVIPANEL V3 for Microdevked with the Pedal-USB option

Photos with different device views:

Device variant front **Eurorack 3U/HP/P** with BHP front panel pedal USB

Device variant rear **Eurorack 3U/HP/P** with BHP front panel pedal USB

Cover variant rear **right Eurorack 3U/HP/P** with BHP front panel pedal USB

Cover variant rear **left Eurorack 3U/HP/P** with BHP front panel pedal USB

Eurorack 3U/HP/P cover variant with BHP front panel pedal USB

Device variant solder side **Eurorack 3U/HP/P** with BHP front panel pedal USB

15) Appendix A.

As of: September 18, 2025

Sources / Links / Product recommendations

- Bermuda rail: print tool / solder / Link to the product:
https://www.bertenshop.com/de/shop/catalogue/produktdetails/b-b-255-end-bugelgeteilt-kombination-vario-b-40g
- Solder / Link to the product:
https://www.conrad.de/de/p/stannol-hs10-5-loetdraht-bleifrei-spule-sn99-3cu0-7-mm?c=169-1-ren-588762.html
- Soldering extraction system / Link to the product:
https://www.reichelt.de/de/en/shop/product/soldering_fume_extraction_set_with_activated_carbon_filter_and_hose_clamp_for_soldering_arm-288762.html?&trstct=pos_0&nbc=1
- Resistor color code table: https://www.elektronik-kompendium.de/sites/bau/1109051.htm
- Current software for NaviPanel V3 is available at: https://codeberg.org/pyrofyter/Microdevked-touch/releases
- Current original manual from Microdevked (Kvitsveet):
https://codeberg.org/pyrofyter/Microdevked-touch/src/branch/main/Microdevked-touch-manual.pdf
- pcb.com Teensy Software: https://www.pjrc.com/teensy/loader.html
- Link to the Midi Remote Control: https://codeberg.org/pyrofyter/Midi-CC
- Link to the Midi Remote Console: https://codeberg.org/pyrofyter/Midi-Console
- AXCELL USB Isolator Module, Industrial Isolator Protection Against Audio Noise, 1500V Digital Module:
https://www.amazon.de/dp/B07L6JR6TP?tag=m_pcl3m_dt_fl_fwd_em_00e
- Midi cable red pack of 3 (audiophonic TYPE A):
https://www.thomann.de/de/audiophonic_midi_cable_a_blue.htm
- Midi cable grey 5-pack (audiophonic TYPE A):
https://www.thomann.de/de/audiophonic_5x_midi_cable_a.htm
- 4WD pcb02 cabinet 3DHP (powered):
https://www.thomann.de/de/4ms_pod02_powered.htm
- 4WD pcb02 enclosure 3DHP (unpowered) (musikanalogue.net)
- 4WD pcb02 cabinet 3DHP (unpowered) (**special purchase via Thomann**)
https://www.thomann.de/de/4ms_pod02.htm
- Power supply for Eurorack enclosure 84HP, maximum output power: 15 V / 3 A 45W
https://www.thomann.de/de/4ms_power_brick_45w.htm
- SD case / housing 32HP for NAVIPANEL V1 from musikanalogue.net (musikanalogue.net)
- SD case / housing 32HE for NAVIPANEL V2 from musikanalogue.net (musikanalogue.net)
- SD case / housing 32HP for NAVIPANEL V3 from musikanalogue.net (musikanalogue.net)
- USB-C Charge/Power Supply Breakout (25 pieces):
https://www.amazon.de/dp/B0CQ6FTP4P?tag=pcbn_dt_fl_fwd_em_00e

16) Appendix B. Credit

Contributors

Mark Kvitsveet aka @pyrofyter (https://discord.gg/N7XYP6SqP)
for the excellent software and hardware team.

Holger Wirtz for the original port of the RP2040 PCI-Desktop OS to the Teensy 4.1 MICRODEVKED - Microcontroller

Thomas Eberle (**https://musikanalogue.net** Hardware development and panel / PCB design

Nicole Eßwein - **https://eisenvogelmanufaktur.de** for her patience with the seemingly endless processing of the assembly instructions and technical documentation.

17) Appendix C.

License and copyright

Creative Commons Attribution-NonCommercial 4.0 International (CC BY-NC 4.0)

You are free to:

Share – to copy and redistribute the material in any medium or format. Adapt – to remix, transform, and build upon the material.

The licensor cannot revoke these freedoms as long as you comply with the license terms.

Under the following conditions:

Attribution – You must give appropriate credit, provide a link to the license, and indicate any changes. This is acceptable, but not in a way that suggests the licensor endorses you or your use.

Non-commercial – You may not use the material **for commercial purposes** .

No further restrictions – You may not apply any legal provisions or technological measures that legally prevent others from performing the acts permitted by the license.

Notes:
You are not required to comply with the License for any portion of the Material that is in the public domain or whose use is permitted by an applicable exception or limitation.

No warranties are provided. The license may not grant you all the permissions necessary for your intended use. For example, other rights such as publicity, privacy, or moral rights may restrict your use of the material.

The full license text can be found at
https://creativecommons.org/licenses/by-nc/4.0/legalcode

Project: NAVIPANEL V3 for Microdevked
Author: Thomas Eberle, (all hardware versions V3-R04-(SD / V3-R03-(SD+SM1, V3-R02-(SM, V3-R01-(KM, V3-R02-v73, V3-R02-(4K)
Author: Mark Kvitsveet, (Software Microdevked Version 1.0.8.4 / 3.8.9)
Email: info@musikanalogue.net
Date: 23.09.2025
Version: V 1.0.0E (this document)
License: Creative Commons Attribution – Non-Commercial 4.0 International (CC BY- NC 4.0)

18) Appendix D.

Technical data BTE front panel pedal USB / September 22, 2025

BTE front panel for Pedal USB / Navipanel mainboard from V3-R05-v54+

Print PDF

NAVIPANEL V3 BTE front panel pedal USB / Date: September 22, 2025	Technical data sheet	3D-(BOM)	X18/Y18 Pitch
C1 Modular mark 3U / 4HP / Dimensions 28 x L in Ø 28N/Y25/Green	Eurorack	optional... (*1)	
C2 Desktop Eurorack Behringer 19/1TE / Dimensions 28 x L in/ 54N/Y25/Green	Metal housing	optional... (*1)	
C3 Desktop aluminum case 4WD pcb02 powered / Dimensions 28 x L in/ 256x154x84mm	Metal housing	optional... (*1)	
C4 power supply USB-C Power Supply Breakout and 4WD 45W Power Brick)	Power supply	optional... (*1)	
C5 Eurorack bus connector with 20cm ribbon cable	for modular (+5V)	Eurorack cable	
B1 16-pin box connector with 20cm ribbon cable	for BHP Eurorack front panel	Eurorack cable	1-16
B2 Ethernet / external supply for USB-hub	switchable	included	
B5 from USB-HOST-Hub Port 4, To USB-A of which are NOT in the front panel	from active USB hub UK	UK (Mainboard)	
B6 16 x USB-A connectors on the back panel	USB-A 2.0	USB HOST-HUB	
B10, 1x S1 Switch Eurorack Power LEDs WHITE	S1 Switch Eurorack PWR	S1 Switch	
B11 1x S2 Switch Powered for Vitrals, LED GREEN	S2 Switch Powered	S2 Switch	
C3 CLOCK OUT TRS 3.5mm 5/8V optocouples	modular connection	TRS 3.5mm	5
C4 CV IN / Attenuverter Input 1/4 inch TRS Jack -5[NE-(5[NP-(5[NE Amphenol Corec.)	modular connection	TRS 6.35mm	6/4
C4 CV IN / attenuator 5-0V(DC / 5-10VDC input (protected with suppressor diodes)	modular connection	TRS 6.35mm	6/4
C5) PEDAL SUSTAIN IN + SUSTAIN 5V-0.5V+ 2.CHANNEL(H) (Amphenol Corec.)	modular connection	TRS 6.35mm	12/10
C6) LED52 CLOCK OUT (front panel)	LED 3mm low current RED	LED2	7
C7) LED 3V Power	LED 3mm low current RED	LED1	14 (VCC +5V)
B6) LED3 +5V Eurorack power	LED 3mm low current RED	LED3	
B5) LED4 +5V Eurorack power	LED 3mm low current RED	LED4	
C8) HOT LED52 Expansion connector 10pcs for BTE front panel with 60° 2x5pol.	MIDI In CV / Pedals - LEDs	X1W	1/2/8 (GND)
Z1) Expansion connector 10pcs for BTE front panel with Eurorack compatible	MIDI In CV / Pedals - LEDs	X1	1/2/8 (GND)
Z2) Expansion connector 10-pin		X1/X1W	3 (ADR0)
Z3) Expansion connector 10-pin		X1/X1W	16 (VDD +12V)
Note 1) the technical data apply from motherboard version and the Navipanel V3 mainboard is necessary! Used Eurorack min. 4HP/3U	V3-R05-v54+, July 02, 2025		
Mid-Si-Co PCB version (Breakout Board V3.0) with CV and Gate, Pedals and USB-A4	V3-R03-(SM, August 21, 2025		
Note 2") only on the smaller pedal / USB PCB version (PEDAL-USB-Breakout-Board) without Mid to CV and Gate OUT	V3-R02-v73, July 02, 2025		

Generated by **wpDataTables**

19) Appendix E.

BOM Part-list for NAVIPANEL BTE-Frontpanel-Pedal-USB

Pedal - USB V2-R03-v84 / 09-22-2025

Print PDF

Show entries Seek

part	Value	Detailed Description
C2	100nF	CAPACITOR
CLOCK OUT	WQP518MA-MONO	Black Thonkiconn Mono 3.5mm Audio Jacks
EURORACK_CABLE	Flatcable_16pol_25cm	Flatcable_16pol_25cm
H1	STANDOFF_M3XTHm_I1_V2A	STANDOFF_M3XTHm_I1_V2A
H2	STANDOFF_M3XTHm_I1_V2A	STANDOFF_M3XTHm_I1_V2A
H3	STANDOFF_M3XTHm_I1_V2A	STANDOFF_M3XTHm_I1_V2A
H3S+H1	2x_WASHER_DIN125A_3.2mm_for_distance	2x_WASHER_DIN125A_3.2mm_for_distance
H4	STANDOFF_M3XTHm_I1_V2A	STANDOFF_M3XTHm_I1_V2A
H4S	1x_NUTS_DIN127_M3_for_Standoff_M3x1	1x_NUTS_DIN127_M3_for_Standoff_M3x18mm
H5	STANDOFF_M3XTHm_I1A_brass	STANDOFF_M3XTHm_I1A_brass
H5S+H5	5x_SCREWS_M3x5mm_ISO7380-1_V2A	5x_SCREWS_M3x5mm_ISO7380-1_V2A
JUMPER	JUMPER 3-pin	JUMPER 3-pin
LED1	LED1+(A)	3mm_red_low_current
LED1-4_STANDOFF	4x_LED3mm-STANDOFF_d3x6mm	4x_LED3mm-STANDOFF_d3x6mm (0201924Z1)
LED2-LED-CLOCK	LED2-CLOCK-OUT	3mm_red_low_current
LED3	LED3+(V	3mm_red_low_current
LED4	LED4+(V	3mm_red_low_current
PCB_BREAKOUT	BTE-Mid-to-CV-Pedal-USB_V3-R02-v76_02-07-2025	BTE-Mid-to-CV-Pedal-USB_V3-R02-v76_02-07-2025
PCB_BREAKOUT1	Amphenol-TRS-6.35-Breakout-v48_20-08-2025	Amphenol-TRS-6.35-Breakout-v48_20-08-2025
PCB_BREAKOUT2	BTE-Frontpanel-Pedal-USB_V1-v7_25-05-2025	BTE-Frontpanel-Pedal-USB_V1-v7_25-05-2025
R1	680R	RESISTOR, European symbol
R2	680R	RESISTOR, European symbol
R3	1K0	RESISTOR, European symbol
R4	1K0	RESISTOR, European symbol
S1	PWR Eurorack / DPDT Latching Push Button WHITE	DPDT Latching Push Button WHITE thonk.co.uk
S2	Powerbt Volume/DPDT Latching Push Button GREEN	DPDT Latching Push Button GREEN thonk.co.uk
TRS SUSTAIN	1x Amphenol-TRS-6.35mm_Jacks-vertical	1x Amphenol-TRS-6.35mm_Jacks-vertical-KLDS-MV-3
TRS VOLUME	1x Amphenol-TRS-6.35mm_Jacks-vertical	1x Amphenol-TRS-6.35mm_Jacks-vertical-KLDS-MV-3
TRS-X8	1x pin header 8pol for TRS breakout	1x pin header 8pol for TRS breakout
USB-A-CABLE	1x USB4_-Cable_25cm_4pin	1x USB4_-Cable_25cm_4pin
X1	Expa Board BTE	HARTING
X1W not used	Expa Board BTE not used	PIN HEADER 2x 8pol 90° not used
X2	EURORACK_IN	HARTING
X3	Vertical Top Entry USB Connector KLDBVX Series	Vertical Top Entry USB Connector KLDBVX Series
X4B	USB-4	PIN HEADER 1x4pin
X5	EURORACK POWER	PIN HEADER 1x5pin
X6	EURORACK GATE/CV	PIN HEADER 1x2pin
X7	TRS breakout female 6-pin	FEMALE HEADER 6-pin

Generated by **wpDataTables**

20) Appendix F

Changes:

Changelog from May 21, 2025 to July 2, 2025

BTE front panel pedal USB / PCB version V1-R01 mit 3 May 2025, 2025
BTE front panel mid-to-CV / pedal USB / PCB version V3-R01-v73 from May 31st, 2025
BTE front PCB / mid-to-CV / pedal USB / PCB version V3-R02-v76 from July 2, 2025

- PCB longer will for Amphenol-TRS-6.35mm widespread
- Plug only X7/8 changed to socket only

21) Appendix F

Changes:

Changelog from 02.07.2025

BTE front panel pedal USB – PCB version V3-R02-v84 from September 21, 2025

- Parts bits as subpoppers for components that are included in the scope of delivery but are not directly located on the PCBs
- minimal corrections to the PCB labeling

NAVIGATION

- Home
- Blog
- Shop
- My Account
- Shopping Cart
- Checkout
- Shipping methods
- Payment methods
- Return policy
- Authenticity of reviews
- About musikanalogue

DOWNLOADS / LINKS

- All downloads
- Upcoming news
- Construction instructions NAVIPANEL V2 V7.5-(2)
- Assembly instructions BASE-for-(TH-PEDAL-USB-V1-0.pdf
- Assembly instructions for the BHP front panel
- BOM for V3-***-V1-0.ods
- Assembly instructions PEDAL-USB-V1-0.pdf
- Assembly instructions for the BHP front panel PEDAL-USB-V1-0.pdf
- midi_PEDAL-USB_V1-0.ino
- midi_PEDAL-USB_V1-0-(4WD-SPC-1-0-3
- midi_PEDAL-USB_V1-0-(4WD-SPCP_1-0-3
- Microdevked-touch-manual-version-0.57.pdf
- codeberg.org/pyrofyter/Midi-Console-touch
- Midi-Microdevked-MDT-remote

NAVIPANEL V3 | NAVIBUTTON V2

EURORACK FRONT PANELS

FOLLOW US ON

Imprint | Privacy Policy | Cookie Policy | Terms and Conditions | Cancellation Policy

DELIVERY / PAYMENT

All prices are in euros (€) and include VAT, plus shipping costs. Subject to change without notice. Product images may vary. While stocks last. Our delivery area is currently Germany, Austria, and selected EU countries. Deliveries to Switzerland, the UK, and Canada are available upon request. The closest-out prices correspond to the previous prices in our shop.
Last update: August 26, 2025

PAYMENT OPTIONS

VISA MC

Copyright © All rights reserved | Web design by musikanalogue